
Pz.Kpfw.III Ausf.M mit schürzen



In February 1934, following the specifications ordered by Hans Guderian, the Armaments Department ordered the development of a new tank, code-named "Zugführerwagen" or 24,000 kg (53,000 lbs.) and a top speed of 35 km/h (22 mph). Four companies responded with designs for the contract: Daimler-Benz, Krupp, MAN, and Rheinmetall. After testing

The basic design layout of the Panzer III was the same as the previous Panzer I and II, with the gearbox at the front and the engine at the rear of the hull. The turret was an enlarged version of the one used on the Panzer II, able to house three of the five-man crew (commander, gunner and loader). This new arrangement dramatically improved the fighting power of the tank by increasing its rate of fire.

Powered by the Maybach HL120TRM engine, the Pz. III Ausf M was nearly identical to the previous Ausf L, with the same 5cm KwK39 L/60 gun and extra 20mm spaced armour on the mantlet and superstructure front, but had three 90 mm (3.54 in) NbK smoke dischargers mounted on both sides of the turret and 5mm thick steel skirts surrounding the turret and sides of the hull to help protect against higher caliber weapons. It also featured fording equipment, which allowed it to wade through up to five feet of water. This was achieved by providing watertight covers for every opening below the turret, including the engine air intakes. Air was provided via the turret while the tank was fording.

This variant was used to replaced front line losses, and took part in the battle of Kursk and the defense of Sicily, although by then its 5cm gun was virtually ineffective in tank-vs-tank dismantled.

03.02.8002

READ BEFORE ASSEMBLY

CAUTION

- Read carefully and fully understand the instructions before commencing assembly. A supervising adult should also read the instructions if a child assembles the model.
- ●When assembling this kit,tools including knives used. Extra care should be taken to avoid personal injury.
- Keep out of reach of small children. Children must not be allowed to suck any part, or pull vinyl bag over their heads.









Optional Instant Glue for Metal

Do Not Cement

PAINTS REQUIRED

Color info and profiles by Mig Jimenez

Rubber &

A.MIG-0034 Rust Tracks

Gun Metal

MIG-0042 Old Rust

Old Wood

New Wood

MIG-0010 RAL 7028 Dunkelgelb (MID WAR)

RAL 6003 Olivgrun OPT.1


RAL 6003

Olivarun OPT.2


Light Wood

APPLYING DECALS

- 1.Clean the model surface with a wet cloth.
- 2.Cut out each decal design from sheet, and dip it in tepid water for 15~20 sec.
- 3. Hold the backing sheet edge and slide decal onto the model.
- 4. Move decal into position by wetting decal with finger.
- 5. Press decal gently down with a soft cloth until excess water and air bubbles are gone.




REMOVING PE



Be careful not to hurt when removing PE parts.





Secure using instant glue (not included).





Finish using file.


PARTS







































PANZER III AUSF.M 2PD 521

migimenez.com



PANZER III AUSF.M_3SS_II5








PANZER III AUSF.M_6PD_601





PANZER III AUSF.M_11PD_421





2020/8002

