

General instructions for the correct assembly of the metal tracks.

1. Check the package contents.
2. Remove the small metal parts of the melting channels.
3. After this it is recommended, with a 0.5 mm drill bit, to clean the track holes. It is not necessary to drill completely on one side, because on one side the hole must remain closed.
4. Wash the tracks in warm water with the addition of a detergent. Allow to dry.
5. Cut the thread slightly shorter than the track hole. A test is recommended. Once the length of the wire is correct, it is advisable to cut a certain number. These will be the trackpins.
6. Insert the track pins into the holes to connect the links.
7. Use cyanoacrylate glue to fix the trackpin. Painting.

0,5