



How to Assemble FoG Models and painting guide.

The following techniques will work with most plaster building kits,

First, a word about plaster kits. Because of the casting process, most have detail on every surface except the back of the casting, which is usually the interior. Since the interior walls are usually fairly flat anyway, this is easy to overcome because you can add wallpaper, wood panelling, trim or whatever if you decide you need to detail the interior of the building.

Most plaster kits are comprised of just a few simple parts that need to be glued together, as most of the detail is cast right in place. That means you can get past the assembly pretty quickly & get right to the fun part, painting & detailing your building.

These basic instructions should work for most plaster kits & even scratch built projects you may do in the future.

This kit has just two main parts. Before gluing them together take a minute or two to clean up the edges with sand paper or wet and dry paper and make sure that you understand how they fit together.

We prefer 5 minute epoxy for assembling plaster parts. You can use white or any household glue like EVO stick or UHU glue. You could also use super glue, but since the plaster is so porous you'd need to use a lot of it.

The 5 minute epoxy gives you enough time to make sure that the parts are straight and true, but you don't have to wait all day for it to set. Mix up a small amount of the epoxy and glue the parts together. Be careful to not use too much glue, or it could squash out & mark the surface of your model. If some oozes out wipe it off ASAP.

All FoG rock plaster models can be cut (as seen right), drilled, shaped and sanded with care, to produce your own unique diorama.

This allows for models to be 'added' together to create bigger or different models, allowing you to make a truly personalized model, you can also combine kits to create bigger and different dioramas.

While in most cases plaster buildings fit together pretty well if you feel there are any seams or joints you want to hide you can use standard lightweight household filler. Once dry you can sand it back easily.

On to the painting!

We suggest priming plaster castings before adding any colour. This will take some of the porosity out of the plaster so that when adding colours they do not soak in instantly. In other words, you're not looking to give the castings so many coats of primer that the parts are hard, shiny and completely waterproof (like plastic), but rather, that they just don't soak in the colours as quickly. That way you'll have a little "work time" with your colours and will be able to move them around a bit & even "wash" them off a bit if they are too dark.



